

The background features a dark grey gradient with a white line-art outline of an acoustic guitar. The Ibanez logo is prominently displayed in the upper center in a white, elegant script font. Below the logo, the text 'IBANEZ ACOUSTIC GUITAR' is written in a clean, white, sans-serif font. The guitar outline shows the neck, fretboard, soundhole, and bridge area.

Ibanez


IBANEZ ACOUSTIC GUITAR

前置信息

AEQ-2U

WWW.IBANEZACOUSTIC.COM

AEQ-2U



基本控制部分

VOLUME

控制前置放大器的整体增益。

TREBLE

控制高音频率的增强 / 减弱

BASS

控制低音频率的增强 / 减弱。

调音器功能

调音器 ON/OFF (打开 / 关闭) 开关

按下音量旋钮可打开/关闭调音器功能。待机 5 分钟后调音器将自动关闭。

音调指示灯



这些指示灯指示正在演奏的弦对应的音调。当调节大调或降调如 G# 时，G 指示灯和 # 指示灯都将亮灯。当音调指示灯指示的音调与所希望的音调不同时，可拧紧或放松对应的弦，直到亮起正确的指示灯为止。当心不要将弦拧得太紧，否则可能会断弦。当无法确定时，最好先放松琴弦调低音调，然后再逐步拧紧调到所需要的音调。

调音指示灯

当弦处于正确音调时，中间的绿色指示灯将亮灯。当该弦处于降调时，左边的红色指示灯将亮灯。当该弦处于大调时，右边的红色指示灯将亮灯。

注释

若注意到如下现象，请更换电池：

- 音质或音量下降
- 打开时调音器没有反应
- 打开调音器时 LED 指示灯没有反应
- 电池检查 LED 指示灯亮灯或闪烁

为了避免无谓地消耗电池电量，当不使用吉他时，请从输出接口拔出插头。

※ 请按照当地法律法规处置废弃电池。

※ 产品外观和规格若有变更，恕不另行通知。

