


# HC43BWN Boom Cymbal Stand

Production from Jan. 2019



No.	Model No.	Description
<b>1</b>	HC42WN1	<b>Base assembly</b>
1-1	RFC4WP3	Rubber tip (3pcs/set) for double braced leg
1-2	TTR816P	T-bolt (M8x16mm, 2pcs/set)
1-3	NB2522T	Nylon bushing (25.4mm-22.2mm) , plate & nut assembly
<b>2</b>	HC42WN2	<b>Center tube assembly</b>
2-1	NB2219T	Nylon bushing (22.2mm-19.1mm) , plate & nut assembly
<b>3</b>	HC43BWN3	<b>Upper tube assembly</b>
3-1	HC43BWN32	Boom tilter assembly
3-11	TTN8P	T-nut (M8) 2pcs
<b>4</b>	HC43BWN4	<b>Boom arm w/ tilter</b>
4-1	B835TTN8WS	Bolt (M8x35mm), washer, spring & nut assembly
4-11	B835	Bolt (M8x35mm)
4-2	CT33Q	Cymbal tilter assembly
4-21	CT331	Cymbal tilter only
4-22	RB8P	Cymbal bottom (2pcs/set)
4-23	7081P	Felt washer (2pcs/set)
4-24	QC8	Quick set cymbal mate