HC32W Cymbal Stand <Discontinued>

Production from May. 2006 to Feb. 2015



No.	Model No.	Substitutable Model No.	Description
1	HC32W1 (Discontinued)	HC42W1	**Base assembly**
1-1	RFDWP3 (Discontinued)	RF3WP3	**Rubber tip (3pcs/set) for double braced leg**
1-2	TS816P		**T-bolt (M8x16mm, 2pcs/set)**
1-3	HB840WN8L		**Bolt (M8x40mm), L-plate & nut assembly**
1-31	WN8P		**Wing nut (2pcs/set)**
1-4	NB2219		**Nylon bushing (25.4mm-19.1mm)**
1-5	INS19N		**Insert (Stabilizing) bushing (25.4mm-19.1mm)**
2	HC32W2 (Discontinued)	HC42W2	**Center tube assembly**
2-1	HB840WN8L		**Bolt (M8x40mm), L-plate & nut assembly**
2-11	WN8P		**Wing nut (2pcs/set)**
2-2	PB191H (Discontinued)	N/A	**Nylon bushing (19.1mm-15.9mm)**
3	HC32W3 (Discontinued)	HC42W3	**Upper tube assembly**
3-1	IRC15N (Discontiued)	N/A	**Insert rubber cap assembly**
3-2	B835WN8T		**Bolt (M8x35mm), washer, spring & nut assembly**
3-21	WN8P		**Wing nut (2pcs/set)**
3-22	B835		**Bolt (M8x35mm)**
3-3	CT33 (Discontinued)	CT33Q	**Cymbal tilter assembly**
3-31	CT331		**Cymbal tilter only**
3-32	RB8P		**Cymbal bottom (2pcs/set)**
3-33	7081P		**Felt washer (2pcs/set)**
3-34	CM8P		**Cymbal mate (M8, 2pcs/set)**