HC43BSN Boom Cymbal Stand

Production from Jan. 2019



No.	Model No.	Description
1	HC42SN1	**Base assembly**
1-1	RFC4SP3	**Rubber tip (3pcs/set) for single braced leg**
1-2	TTR816P	**T-bolt (M8x16mm,2pcs/set)**
1-3	NB2522T	**Nylon bushing (25.4mm-22.2mm) , plate & nut assembly**
2	HC42WN2	**Center tube assembly**
2-1	NB2219T	**Nylon bushing(22.2mm-19.1mm) , plate & nut assembly**
3	HC43BWN3	**Upper tube assembly**
3-1	HC43BWN32	**Boom tilter assembly**
3-11	TTN8P	**T-nut (M8) 2pcs**
4	HC43BWN4	**Boom arm w/ tilter**
4-1	B835TTN8WS	**Bolt (M8x35mm), washer, spring & nut assembly**
4-11	B835	**Bolt (M8x35mm)**
4-2	CT33Q	**Cymbal tilter assembly**
4-21	CT331	**Cymbal tilter only**
4-22	RB8P	**Cymbal bottom (2pcs/set)**
4-23	7081P	**Felt washer (2pcs/set)**
4-24	QC8	**Quick set cymbal mate**